

How to Install Clicker Assembly


Step 1

Place the middle of the spring over spring support.



Step 2

Screw in the second spring support and tuck the end of the spring under the support.



Step 3

Install the pawl (or clicker claw) in the pawl carrier.
Tuck the other end of the spring below the pawl.

